
Index

A

- accessing Configuration/Setup Utility program 4-7
- activity monitor option 4-20
- adapter slot position 3-5
- adapters, installing 3-8
- add
 - cache memory 3-6
 - drivers 2-2
 - internal drive 3-11
 - memory module kits 3-4
 - memory modules 3-4
 - processor card 3-3
 - system memory 3-4
- address conflicts 5-7
- administrator password option 4-14
- advanced CPU setup option 4-16
- advanced power management option 4-19
- advanced setup option 4-15
- air filters 4-2
- APM BIOS mode option 4-19
- application-specific drivers 4-20
- assignments, serial port 4-23
- automatic power management (APM) 4-20

B

- backplane
 - connectors D-3
 - removing and replacing 8-40
- backplane parts 9-2
- backplane, removing and replacing 8-40
- battery failure error message 5-10
- battery, memory-retention 4-22
- baud rate (definition of) 4-23
- beep symptoms 8-15
- beeps, POST 8-3
- BIOS level 8-2
- BIOS, updating 4-28
- blank screen 5-5
- boot error, hard disk 8-28
- broken cover lock 5-6
- bus card connectors D-3

C

- cable connectors D-3
- cables
 - disconnecting 8-29
 - part numbers 9-9
- cables, connecting 2-2
- cache control option 4-16

- cache memory, installing 3-6
- CAD Panacea video drivers, installing F-6
- card
 - connectors D-3
 - hold-down spacers 3-9
- change
 - configuration information 4-6, 4-8
 - jumpers D-1
 - logical unit numbers 8-8
 - resolutions F-3, F-4
 - selected tests in test groups 8-9
 - serial port assignments 4-24
- channel assignments, DMA E-2
- check voltage range 2-1
- checkouts
 - beeps 8-15
 - display 8-14
 - general 8-10
 - keyboard 8-11
 - Module Tests Menu 8-6
 - no beeps 8-16
 - power supply 8-13
 - power-supply connections 8-13
 - printer 8-12
- code page 4-28
- color graphics adapter (CGA) 4-27
- color, high resolution 4-27
- COM1 serial port 4-23
- command-line options 8-7
- communications 4-24
- component layout
 - 7588 Industrial Computer 1-2
 - processor card 6-2
- configuration
 - 7588 Industrial Computer 4-1
 - activity monitor 4-20
 - administrator password 4-14
 - advanced power management 4-19
 - advanced setup 4-15
 - APM BIOS mode 4-19
 - cache control 4-16
 - changing 4-6
 - conflicts 4-5
 - CPU advanced setup 4-16
 - date and time 4-12
 - device change 5-13
 - DMA resources 4-18
 - drive security option 4-13
 - errors 4-5
 - ethernet setup 4-16
 - hardware change 5-9
 - I/O port resources 4-18

configuration (*continued*)

- interrupt resources 4-19
 - ISA legacy resources 4-17
 - memory change 5-13
 - memory resources 4-17
 - overview 4-4
 - PCI control 4-16
 - plug and play control 4-16
 - power-on password 4-13
 - product data 4-8
 - ROM shadowing 4-16
 - start options 4-14
 - system security 4-13
 - system summary 4-8
 - utility program 4-6
 - video 4-28
 - viewing information 4-8
- ## Configuration/Setup Utility program
- activity monitor option 4-20
 - administrator password option 4-14
 - advanced power management option 4-19
 - advanced setup 4-15, 4-16
 - APM BIOS mode option 4-19
 - cache control option 4-16
 - date and time option 4-12
 - description 5-1
 - devices and I/O ports option 4-9
 - DMA resources 4-18
 - drive security option 4-13
 - ethernet setup 4-16
 - hard disk drive option 4-11
 - I/O port resources 4-18
 - IDE drives setup option 4-11
 - interrupt resources option 4-19
 - ISA legacy resources 4-17
 - main menu screen 4-7
 - memory resources option 4-17
 - moving around in the screens 4-7
 - options
 - activity monitor 4-20
 - administrator password 4-14
 - advanced power management 4-19
 - advanced setup 4-15
 - APM BIOS mode 4-19
 - cache control 4-16
 - CPU advanced setup 4-16
 - date and time 4-12
 - devices and I/O ports 4-9
 - DMA resources 4-18
 - drive security option 4-13
 - ethernet setup 4-16
 - hard disk drive 4-11
 - I/O port resources 4-18
 - IDE drives setup 4-11
 - interrupt resources 4-19
 - ISA legacy resources 4-17
 - memory resources 4-17

Configuration/Setup Utility program (*continued*)

- options (*continued*)
 - PCI control 4-16
 - plug and play control 4-16
 - power-on password 4-13
 - product data 4-8
 - ROM shadowing 4-16
 - start options 4-14
 - system security 4-13
 - system summary 4-8
 - video setup 4-10
 - PCI control option 4-16
 - plug and play control 4-16
 - power-on password 4-13
 - product data option 4-8
 - ROM shadowing 4-16
 - run 2-3
 - selecting a monitor F-2
 - service procedures 8-1
 - start options 4-14
 - starting 4-7
 - system security option 4-13
 - system summary 4-8
 - use 4-6
 - video setup option 4-10
- ## conflicts, eliminating assignment 5-7
- ## connecting cables 2-2
- ## connectivity A-2
- ## connectors
- backplane (12J2727) D-4
 - backplane (76H4355) D-3
 - bus card D-3
 - cable D-3
 - processor card 6-4
- ## cover lock, broken 5-6
- ## cover, remove 3-2
- ## covers (FRUs) 9-7
- ## CPU setup option 4-16

D

- data, transferring 4-24
- date and time option 4-12
- date and time, setting 4-12
- default resolutions F-1
- detecting POST errors 5-1, 5-2
- device configuration error 5-13
- device drivers
 - adding 2-2
 - application specific 4-20
 - device specific 4-20
 - installing 2-2
 - installing CAD Panacea F-6
 - installing MicroStation PC F-7
 - installing OS/2 F-5
 - installing Windows 3.1 F-2

- device drivers (*continued*)
 - installing Windows 95 F-4
 - installing Windows NT F-5
 - overview 4-20
 - S3 Trio64V+ video F-1
 - video 4-26
- device records B-1
- devices and I/O ports option 4-9
- devices, handling discharge-sensitive A-15
- diagnostic
 - command-line options 8-7
 - diskette 5-1
 - error messages 5-2, 5-13
 - errors 5-9
 - programs 5-1
 - QAPlus/PRO program 8-5
 - starting diagnostic program 8-8
 - tests, extended memory 8-8
 - tools 5-1, 8-3
- dimensions
 - See physical dimensions
- direct memory access (DMA) channel
 - assignments 4-21, 4-22, E-2
- discharge-sensitive devices, handling A-15
- disconnecting cables 8-29
- diskette
 - diagnostic programs 5-3
 - Diagnostics 5-1
 - drive access 4-3
 - drive in-use lights 5-3
 - drive replacement 8-32
 - parts 9-4
 - parts catalog 9-4
 - security option 4-13
 - starting the diagnostic program 8-8
 - update 4-28
- diskettes drives, security 4-13
- display
 - blank screen 5-5
 - checkout 8-14
 - distorted screen 5-5
 - error codes 5-2, 5-8
 - jitter 5-5
 - problems 5-5, 5-8
 - rolling screen 5-5
 - selecting 4-27
 - self-tests 5-4
 - support 4-27
 - SVGA 4-26
 - wavy screen 5-5
- DMA channel assignments 4-21, 4-22, E-2
- DMA resources option 4-18
- drives
 - CD-ROM 9-4
 - CD-ROM drive replacement 8-32
 - diskette 9-4

- drives (*continued*)
 - diskette drive replacement 8-32
 - hard disk 4-11
 - hard disk (FRUs) 9-7
 - hard disk boot error 8-28
 - hard disk jumper settings D-2
 - in-use lights 5-3
 - installing external device 4-25
 - installing internal 3-11
 - replacing hard disk 8-33
 - security option 4-13

E

- EEPROM, Flash 4-28
- electrical safety A-11
- electronic emission A-2
- electrostatic devices, handling A-15
- emission, electronic A-2
- enhanced graphics adapter (EGA) 4-27
- environment 1-4
- errors
 - battery failure 5-10
 - beep symptoms 8-15
 - code format, POST 8-4
 - configuration 4-5
 - detecting POST 5-2
 - device configuration 5-13
 - diagnostic 5-9, 5-13
 - hard disk boot error 8-28
 - memory configuration 5-13
 - message types 8-4
 - messages 5-2, 5-8, 5-9, 8-21
 - numeric codes 8-17
 - POST 4-6, 5-2, 5-9, 5-10
 - prompt 5-8
 - software 5-9
 - types of messages 8-4
- ethernet setup option 4-16
- external serial devices, installing 4-24

F

- fan (power supply) problems 5-6
- fans and filters parts 9-6
- feature cards, replacing 8-31
- field-replaceable units (FRUs)
 - backplane 9-2
 - cables 9-9
 - CD-ROM drive 9-4
 - covers 9-7
 - diskette drive 9-4
 - fans and filters 9-6
 - floor-stand kit 9-8
 - hard disk drives 9-7
 - keyboards 9-9

field-replaceable units (FRUs) *(continued)*

- mouse 9-9
- numbers 9-1
- panel-mount kit 9-8
- parts catalog 9-1
- power cord 9-10
- processor card 9-2
- rack-mount kit 9-8
- Flash (BIOS/VPD) update procedure 8-2
- flash, updating 4-28
- flash, verifying revision level 4-28
- flicker 4-26
- floor-stand dimensions C-3
- floor-stand kits, parts 9-8
- front fan, replacing 8-34

G

- general checkout 8-10
- general problems 5-6
- general safety A-10
- graphics 4-26
- grounding requirements A-15
- guide, safety inspection A-14

H

- handling electrostatic-discharge-sensitive devices A-15
- handling static-sensitive devices A-15
- hard disk
 - bad sector 5-8
 - boot error 8-28
 - drive access 4-3
 - jumper settings D-2
 - parts 9-7
 - parts catalog 9-7
 - replacing 8-33
 - secure drives 4-13
 - security option 4-13
 - testing 5-8
- hardware
 - diagnostic error messages 5-13
 - problems 5-1, 8-3
 - testing programs 5-1
- heat output 1-4
- high-resolution color 4-27
- hold-down, card spacers 3-9

I

- I/O port resources option 4-18
- I/O ports, configuration information 4-9
- IBM SBC
 - See processor card
- IDE drives setup option 4-11

- in-use lights 5-3
- indicator lights problem 5-6
- indicators, processor card 6-3
- industry-standard architecture (ISA)-bus adapters E-1
- inspection guide, safety A-14
- install
 - 7588 Industrial Computer 2-1
 - adapters 3-8
 - application programs 4-3
 - cache memory 3-6
 - CAD Panacea video drivers F-6
 - card hold-down spacers 3-9
 - device drivers 2-2
 - external parallel devices 4-25
 - external serial devices 4-24
 - internal drive 3-11
 - internal options 2-2
 - memory modules 3-4
 - MicroStation PC video drivers F-7
 - options 3-1
 - OS/2 video drivers F-5
 - parallel devices, external 4-25
 - processor card 3-3
 - RAM memory module kits 3-4
 - S3 Trio64V+ driver F-1
 - serial devices, external 4-24
 - Windows 3.1 video drivers F-2
 - Windows 95 video drivers F-4
 - Windows NT video drivers F-5
- intermittent problems 5-6
- internal drive, installing 3-11
- interrupt
 - and DMA assignments E-1
 - conflicts 5-7
 - request assignments 4-21, E-1
- interrupt resources option 4-19
- ISA legacy resources 4-17
- ISA-bus adapters E-1

J

- jumpers
 - description D-1
 - processor card 6-11
- jumpers and switches, processor card 4-22

K

- keyboard
 - checkout 8-11
 - problems 5-6
- keyboard part numbers 9-9
- keyboard problems 5-6
- keyboardless operation mode 4-4
- kits, installing RAM memory module 3-4

L

- languages 4-28
- layout
 - 7588 Industrial Computer components 1-2
 - processor card 6-2
- LED assembly, replacing 8-35
- LEDs 4-1
- lights
 - in-use 5-3
 - not working 5-6
- lithium battery 4-22
- lock for cover, broken 5-6
- logical unit numbers, changing 8-8

M

- mass storage device configuration information 4-11
- MCGA (multicolor graphics array) 4-27
- memory
 - configuration error 5-13
 - diagnostic tests 8-8
 - installing RAM 3-4
 - processor card 6-3
- memory resources option 4-17
- Memory Test Group 8-8
- memory-retention battery 4-22
- memory, adding 3-4
- menu, module tests 8-6
- messages
 - battery failure error 5-10
 - device configuration error 5-13
 - diagnostic error 5-9, 5-13, 8-4
 - enter password prompt 5-2
 - error 5-2, 8-21
 - memory configuration error 5-13
 - multiple 8-4
 - POST beep patterns 8-4
 - POST error 5-1, 5-2, 5-10, 8-4
 - software-generated 8-4
 - types of error 8-4
- MicroStation PC video drivers, installing F-7
- module tests
 - running selected 8-9
- Module Tests Menu 8-6
- module tests selection 8-8
- monitor, selecting F-2
- mounting 7588 Industrial Computer 2-2
- mouse part numbers 9-9
- mouse problems 5-6

N

- 9-pin serial port 4-23
- no beeps 8-16

- notices A-1
- numeric error codes 8-17

O

- on/off switch 4-1
- open
 - system unit 8-30
- open 7588 Industrial Computer 3-2
- operator information 4-1
- options
 - adding 3-1
 - problems 5-7
- options, adding 3-1
- OS/2 video drivers, installing F-5
- overview of 7588 Industrial Computer 1-1

P

- panel-mount dimensions C-2
- panel-mount kits, parts 9-8
- parallel devices, external 4-25
- parallel port assignments 4-25
- parallel port mode, changing 4-25
- parts
 - See field-replaceable units (FRUs)
- parts catalog 9-1
 - enhanced keyboard (TrackPoint II) 9-9
 - keyboard cable 9-9
- parts warranty 9-1
- passwords
 - administrator 4-14
 - keyboard 4-4
 - power-on 4-3, 4-13, 5-2, 5-6
 - prompt 5-8
 - removing 4-4
 - system administrator 4-3
- PCI control option 4-16
- physical dimensions
 - with floor-stand C-3
 - with panel-mount C-2
 - with rack-mount C-1
- pin assignments, serial port D-6
- plug and play control 4-16
- PMC video card
 - features 7-1
 - removing and replacing 8-39
- pointing-device problems 5-6
- port assignment conflicts 5-7
- ports, configuring I/O 4-9
- POST
 - See power-on self-test (POST)
- power cord part numbers 9-10
- power supply
 - checkout 8-13
 - connections, processor card 8-13

- power supply (*continued*)
 - fan problems 5-6
 - replacing 8-33
 - specifications 1-4, 4-1
 - power switch
 - feature 4-1
 - replacing 8-35
 - power-on password 5-2, 5-6
 - power-on password option 4-13
 - power-on problems 5-2, 5-7
 - power-on self-test (POST)
 - battery failure error 5-10
 - beeps 8-3
 - description 5-1
 - detecting problems 8-3
 - error 4-6
 - error detection 5-1, 5-2
 - error messages 5-2, 5-10
 - operation 5-1, 5-2
 - problem detecting 8-3
 - updating 4-28
 - power, switching off 8-29
 - printer
 - checkout 8-12
 - problems 5-8
 - problems
 - diskette drive 5-3
 - display 5-5
 - error prompt 5-8
 - fan 5-6
 - forgotten power-on password 5-6
 - general 5-6
 - hardware 5-1
 - hardware related 8-3
 - intermittent 5-6
 - keyboard 5-6
 - mouse 5-6
 - no beeps 5-5
 - occasional 5-6
 - options 5-7
 - overview 5-1
 - password prompt 5-8
 - pointing-device 5-6
 - power-on 5-2, 5-7
 - printer 5-8
 - screen distortion 5-5
 - screen jitter 5-5
 - screen roll 5-5
 - software 5-1, 5-9
 - solving 5-1, 5-2
 - troubleshooting charts 5-3
 - undetermined 8-28
 - user error 5-1
 - wrong number of beeps 5-5
 - wrong screen characters 5-5
 - processor card
 - cache memory 3-6
 - component layout 6-2
 - connectors 6-4
 - features 6-1
 - indicators 6-3
 - installing 3-3
 - jumpers 6-11
 - jumpers and switches 4-22
 - memory subsystem 6-3
 - part numbers 9-2
 - parts catalog 9-2
 - power-supply connections 8-13
 - remove 3-4
 - removing and replacing 8-35
 - SIMMs 3-4
 - switch functions 6-11
 - switch settings D-5
 - updating flash EEPROM 4-28
 - processor chip, removing and replacing 8-37
 - product data option 4-8
 - program
 - Configuration/Setup Utility 5-1
 - diagnostic 5-1, 5-3
 - navigation 8-6
 - power-on self-test (POST) 5-1
 - QAPlus/PRO 8-5
 - system 4-6, 4-28
 - test 8-5
 - utility 4-6
- ## Q
- QAPlus/PRO diagnostic program 8-5
- ## R
- rack-mount dimensions C-1
 - rack-mount kit, parts 9-8
 - RAM memory module kits, installing 3-4
 - range, voltage 2-1
 - records, device B-1
 - remove and replace
 - backplane 8-40
 - CD-ROM drive 8-32
 - diskette drive 8-32
 - feature cards 8-31
 - front fan 8-34
 - hard disk drive 8-33
 - LED assembly 8-35
 - PMC video card 8-39
 - power supply 8-33
 - power switch 8-35
 - procedures for 8-1, 8-29
 - processor card 8-35
 - processor chip 8-37

- remove cover 3-2
- removing the system unit from its mounting 8-30
- replacement parts 9-1
- requirements, grounding A-15
- resolutions
 - changing F-3, F-4
 - default F-1
 - VGA/SVGA 4-26
- restore configuration 4-6
- revision level, verifying flash 4-28
- ROM (read-only memory) 4-28
- ROM shadowing 4-16
- run selected module tests 8-9

S

- S3 Trio64V+ driver, installing F-1
- safety
 - electrical A-11
 - general A-10
 - information A-10
 - inspection guide A-14
- scripting 8-8
- security features 4-3
- security option, drive 4-13
- select monitor F-2
- selected module tests, running 8-9
- selected tests in test groups, changing 8-9
- self-tests, internal 5-1, 5-2
- serial devices, external 4-24
- serial port assignments 4-24
- serial port pin assignments D-6
- service
 - information 8-1
 - parts warranty 9-1
- set date and time 4-12
- shadow ROM 4-16
- SIMMs (single inline memory modules) 3-4
- SIMMs, installing 3-4
- single inline memory modules (SIMMs) 3-4
- single-board computer (SBC)
 - See processor card
- slot position, adapter 3-5
- software
 - errors 5-9
 - problems 5-1, 5-2
- solving problems 5-1
- spacers, card hold-down 3-9
- special characters 4-28
- specifications 1-4
- start
 - Configuration/Setup Utility program 4-7
 - diagnostic programs 5-3
 - system unit 5-2
- start options 4-14

- startup-sequence control 4-4
- static-sensitive devices, handling A-15
- stopping tests 8-9
- storage device, mass, configuration information 4-11
- SVGA
 - advantages 4-26
 - description 4-26
 - languages 4-28
 - software compatibility 4-27
 - special characters 4-28
 - video configuration 4-28
- switch
 - on/off 4-1
 - processor card 6-11
 - voltage-selection 5-2
- switches, processor card D-5
- switching off power 8-29
- symptom-to-FRU index 8-14
- symptoms, beep 8-15
- symptoms, no beeps 8-16
- system memory, installing SIMMs 3-4
- system security option 4-13
- system summary option 4-8

T

- test group, memory 8-8
- test groups, viewing 8-7
- test programs
 - diagnostic 8-5
 - hardware 5-1
 - using 8-5
- test scripts 8-8
- test the system unit 5-2
- tests menu, module 8-6
- tests, stopping 8-9
- time and date, setting 4-12
- tools, diagnostic 5-1
- trademarks and service marks A-1
- transferring data 4-24
- troubleshooting charts 5-3

U

- undetermined problems 8-28
- update
 - flash EEPROMs 4-28
 - system programs diskette 4-28
 - system unit configuration 4-6
- user error problems 5-1
- using QAPLUS/PRO program 8-5
- using test programs 8-5
- utility program, Configuration/Setup 4-6

V

verifying flash revision level 4-28

vertical-refresh rate 4-27

video

configuration 4-28

standards 4-27

video device drivers

See also device drivers

installing CAD Panacea F-6

installing MicroStation PC F-7

installing OS/2 F-5

installing Windows 3.1 F-2

installing Windows 95 F-4

installing Windows NT F-5

overview 4-20

video setup option 4-10

vital product data code 8-2

voltage range 2-1

voltage-selection switch 5-2

W

warranty service parts 9-1

Windows video drivers, installing F-2, F-4, F-5

Readers' Comments — We'd Like to Hear from You

**IBM 7588 Industrial Computer
Installation, Operation,
and Hardware Maintenance
Publication No. S02K-1755-00**

Overall, how satisfied are you with the information in this book?

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Overall satisfaction	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

How satisfied are you that the information in this book is:

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Accurate	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Complete	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to find	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to understand	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Well organized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Applicable to your tasks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Please tell us how we can improve this book:

Thank you for your responses. May we contact you? ☐ Yes ☐ No

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you.

Name

Address

Company or Organization

Phone No.




Fold and Tape

Please do not staple

Fold and Tape



NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

International Business Machines Corporation
WW Production Solutions Information Development
Department 27X, IMAD 2102
1798 N.W. SPANISH RIVER BOULEVARD
BOCA RATON FL 33431-9661



Fold and Tape

Please do not staple

Fold and Tape



Part Number: 02K1755



Printed in the United States of America
on recycled paper containing 10%
recovered post-consumer fiber.

S02K-1755-00



02K1755

